




www.barkbusters.net

FITTING INSTRUCTIONS for...

- BMW RnineT Scrambler ('16 on)
- BMW RnineT Urban G/S ('17 on)
- BMW R 12 G/S ('25 on)



Fitting Procedure shown for the LEFT side



(repeat for right side with applicable parts)

Loosely assemble clamp to the handlebar with applicable parts.
Attach the handguard backbone with applicable parts to the handlebar end and also to the clamp frame.

Note: The preferred backbone position is horizontal when viewed from the side.

Tighten all bolts in the following order (7), (6), then (4) and (5).
Use recommended torque specifications over page.

Bar Side View



Personalise Your Protection Guard options sold separately

JET JET-003




VPS VPS-003

Storm STM-003

CARBON BCF-003



Phone: +61 (0)2 4271 8244
Email: info@barkbusters.net

1 Aluminium Bar  PN: BAR-BV-036 Pcs. 2 (L & R)	2 Clamp Frame & Saddle (left)  PN: CFS-ADV-L-BK Pcs. 1 set	3 Clamp Frame & Saddle (right)  PN: CFS-ADV-R-BK Pcs. 1 set	4 Button Head Bolt 30mm  PN: M6x30BHCSZP Pcs. 2	5 Button Head Bolt 20mm  PN: M6x20BHCSZP Pcs. 2	6 Flat Head Bolt 20mm  PN: M8X20FHCSZP Pcs. 2	7 Flat Head Bolt 60mm  PN: M8x60FHCSZP-FT Pcs. 2	8 Bar End Cap  PN: BEC2 Pcs. 2
9 Spacer  PN: SP17-20-8 Pcs. 2	10 Bar End Expander  PN: BBE12-SH Pcs. 2	11 Nut  PN: NUT10 Pcs. 2					

Recommended Torque Settings	
M6	10 Nm (7.4 lbf ft)
M8	28 Nm (20.7 lbf ft)

CAUTION:

Installation of the handguard is safety-relevant work and can be complicated. We recommend the installation be performed by a motorcycle service technician. Rideworx accepts no liability for damages caused by improper mounting. All screws, bolts and nuts, including all replacement hardware provided by Rideworx, should be tightened to the torque specified in the table. After the first 50km of riding check all screws, bolts and nuts are tightened to the correct torque. We recommend a medium strength liquid thread lock product on all fasteners.

WARNING:

Check operation of all handlebar controls, specifically the throttle, front brake, kill switch and clutch to ensure they are operating correctly and are in accordance with the OEM specifications. Do not ride the motorcycle if any controls are not operating correctly or if rear view mirror vision is obscured. Check periodically that all bolts are tight.

Disclaimer:

A failure to follow these fitting instructions could cause serious injury, death or property damage. These handguards are intended solely for use with motorcycles/ATV/snowmobiles/scooters that have not been modified. They are not designed to prevent injury or death while riding or in an accident or crash. The user must ensure that all controls are free of the handguards every time that they ride. By installing and/or using this product you acknowledge that you accept these terms and have followed the fitting instructions.

INS-BHG-064-00-BK



RIDEWORX

Phone: +61 (0)2 4271 8244
 Email: info@barkbusters.net
 Web: www.barkbusters.net

